

Assembly instructions for work table


Content

- 3. list of parts
- 4. assembly

2. list of parts


m) Hole caps gray		16stk
n) dowel	8x35 mm	12stk
o) Screw	4,5x16mm	50stk
p) M12 safety nut		4stk
q) Hexagon socket head screw	M12x30mm	4stk
r) Roll with brake		4stk
s) Trag profile	1640mm	2stk
t) L profile	1305mm	2stk
u) L profile	1545mm	2stk
v) L profile	1545mm	2stk
w) Table frame		2stk
x) Plate DTDL 18mm	1500x665mm	5stk

picture 1.




assembly

picture 2.



On the table frame
(k)


Screw on castors (f),
profile (h)



picture 3.



Screw on profile (i)



picture 4.



Place the plate on the constriction and connect it with the dowel (b).

Screw on from below with screw (c) in the prepared holes



picture 5.



Screw on profile (j)



picture 6.



Screw on profile (g)

picture 7.



Place the plates (I) on the rack, screw them from below with screw (c) into the prepared holes.

